

CAMERON

A spacious chair in leather or fabric options, the Cameron recliner features air massage and a power lift to make exiting the chair a breeze.



STRUCTURAL
WARRANTY



FOAM
WARRANTY



MECHANICAL
WARRANTY



LEATHER
WARRANTY



ELECTRICAL
WARRANTY



FABRIC
WARRANTY

COLOURS AVAILABLE

STOCKED IN	
	LIVORNO LEATHER (PEARL)
	LIVORNO LEATHER (GREY)
	VELLETRI FABRIC (GREY)
	VELLETRI FABRIC (GRANITE)

SALES COLLATERAL AVAILABLE

- POS PAGE
- 150KG SASH SET
- SPECIFICATION / TRAINING SHEET

KEY FEATURES & BENEFITS

FRAME	FSC certified Pine and Plywood frame	A sturdy frame constructed with sustainably sourced timber provides a solid and long-lasting base to the suite
FOUNDATION	Heavy gauge steel Zig Zag springs	The foundation delivers long-lasting support & the first layer of comfort
FOAM	Premium high-density foam and fibre seat cushioning	Layered high & low density foam delivers seating that lasts without compromising on comfort
MECHANISM	Tested up to 150kgs at 25,000 cycles	Warrantied for use up to 150kgs, this robust recliner mechanism has been crafted to last - that's 30kg more weight-loading than standard mechanisms!
POWER	Powered recliner, headrest and lumbar	Recliners, headrests and lumbar are adjustable at the touch of a button - the ultimate for customised comfort!
POWER LIFT	Powered lift function	Powered lift allows for easy exit out of the chair
AIR MASSAGE	Airbag massage in seat back	Kick back and relax with a soothing 30-minute air-powered massage in the seat back. Allow 10-minutes between massage cycles.
HEATED SEAT BACK	Heating in the seat back	Enhance your massage experience, or just beat the winter chill, with a heated seat back at the touch of a button.
UPHOLSTERY	Livorno leather and Velletri fabric options	Stocked in high quality pearl or grey coloured Livorno leather, and grey or granite coloured Velletri fabric

Scan QR code to view this product on our website



REMOTE CONTROL OPERATING INSTRUCTIONS

Head Rest buttons
Used to adjust the angle of the head rest


Back buttons
Used to adjust the amount of back rest recline

Lumbar buttons
Used to adjust the position of the lumbar area

Footrest buttons
Used to control the extension of the footrest

1, 2, 3, 4 buttons
Used to activate or deactivate particular
massage areas in the backrest:
Zone 1: Lower back •
Zone 2: Middle lower back •
Zone 3: Middle upper back •
Zone 4: Upper back •

Heat button
Used to turn back rest heating on or off. The heating
will run for 30-minutes before automatically turning off.
Allow 10-minutes between heat cycles.



Lift buttons
Used to control the power lift function of the chair

Home button
Push and hold to restore the chair back to the
default or "home" position. Holding the home button
past the default position will activate the lift function
to assist the user out of the chair.

Mode button
Used to cycle between different massage modes:
• Green Light: Pulse Mode
• Blue Light: Wave Mode
• Red Light: Alternating

Power button
Used to turn the back rest massage on or off. The massage
will run for 30-minutes before automatically turning off.
Allow 10-minutes between massage cycles.

Scan QR code to view this
product on our website

