



IMPORTANT: Please read these assembly instructions carefully before beginning assembly. Retain for future reference. **CAUTION:** This product is heavy. Assemble with the assistance of another adult. Do not assemble in the presence of children.




Step 1.

Remove packaging and set aside. Use two people to safely handle all large pieces. On the underside of each piece of the suite is a zippered compartment that contains a package with plastic feet and washers. Retrieve the package with the feet and close up the zippered compartment.



Step 2.


Using one plastic washer per foot, carefully fix the feet into the pre-drilled holes in the corner of each piece (sofas have a centre support foot as well) – careful to not overtighten and risk damage to the feet. Repeat this for every piece of lounge you have purchased.



Step 3.

Using two people again, carefully flip each piece back the right way up – taking care not to rest the weight on the feet until the sofa piece is flat and level.


Arrange your pieces according to desired layout by safely lifting into place with two people, and not dragging the furniture.



Operating Warnings:


- Ensure there is no person, animal or item obstructing the area under the footrest before operating this product.
- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep fingers, hair and body parts well clear from moving parts. To reduce the risk of injury, keep children and pets clear of the product when in use.
- Do not sit or place additional weight on the arms, back or open footrest. Damage caused as a result of excessive force is not covered under warranty.
- This product is very heavy. Only move this product by lifting the main body. Never drag by the footrest, back or arm rest.
- Return this product to the full upright position to stand safely and prevent a tripping hazard.
- Do not operate this product if damage is visible in any form.
- Do not modify or use unauthorised substitute parts.
- This product has been designed and intended for indoor residential use only.
- This product is not suitable for commercial or outdoor use.
- This product is not intended to be used as part of a health care plan. Consult your medical professional before operating if you are taking medication or have physical limitations.
- If recliners are placed on hard floors, there is a possibility the mechanism could scratch the floor and any such damage is not covered under warranty. It is recommended you place the recliner on a non-stick mat in this instance. Should an issue arise with the recliner mechanism, do not use the reclining function until it has been repaired.

IMPORTANT: Please read these assembly instructions carefully before beginning assembly. Retain for future reference. **CAUTION:** This product is heavy. Assemble with the assistance of another adult. Do not assemble in the presence of children.




Step 1.

Remove packaging and set aside. Use two people to safely handle the ottoman. On the underside is a zippered compartment that contains a package with plastic feet and washers. Retrieve the package with the feet and close up the zippered compartment.



Step 2.


Using one plastic washer per foot, carefully fix the feet into the pre-drilled holes in the corners – careful to not overtighten and risk damage to the feet.



Step 3.

Using two people again, carefully flip the ottoman back the right way up – taking care not to rest the weight on the feet until the sofa piece is flat and level.

Arrange your pieces according to desired layout by safely lifting into place with two people, and not dragging the furniture.



Operating Warnings:

- Ensure there is no person, animal or item obstructing the area under the footrest before operating this product.
- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep fingers, hair and body parts well clear from moving parts. To reduce the risk of injury, keep children and pets clear of the product when in use.
- Do not sit or place additional weight on the arms, back or open footrest. Damage caused as a result of excessive force is not covered under warranty.
- This product is very heavy. Only move this product by lifting the main body. Never drag by the footrest, back or arm rest.
- Return this product to the full upright position to stand safely and prevent a tripping hazard.
- Do not operate this product if damage is visible in any form.
- Do not modify or use unauthorised substitute parts.
- This product has been designed and intended for indoor residential use only.
- This product is not suitable for commercial or outdoor use.
- This product is not intended to be used as part of a health care plan. Consult your medical professional before operating if you are taking medication or have physical limitations.
- If recliners are placed on hard floors, there is a possibility the mechanism could scratch the floor and any such damage is not covered under warranty. It is recommended you place the recliner on a non-stick mat in this instance. Should an issue arise with the recliner mechanism, do not use the reclining function until it has been repaired.